

FIG. 1




FIG. 2




FIG. 3




FIG. 4





FIG. 5



**FIG. 6**





FIG. 7




FIG. 8





FIG. 9





*FIG. 10*




FIG. 11




FIG. 12




FIG. 13




FIG. 14

30c: ABNORMAL-MODE CURRENT CONTROL MEANS  
 101: VOLTAGE WAVESHAPING MEANS




FIG. 15




FIG. 16




FIG. 17






FIG. 18




FIG. 19







FIG. 21

